

## ***Studio operations***

**New England Digital Corporation**

**July 1990**

Copyright © New England Digital Corporation, 1990 [1986-89].  
All rights reserved.

All copyrights in these documents, and the software described in them, are the exclusive property of New England Digital Corporation. Copying all of or any part of these documents, or the software described in them, is prohibited, except with the express written consent of New England Digital Corporation. Under copyright law, copying includes translating into another language or format. All permitted copies must bear the copyright notice shown above.

Synclavier, Sample-to-Disk, Direct-to-Disk and The Tapeless Studio are registered trademarks, and Sample-to-Memory is a trademark of New England Digital Corporation.

Apple Computer, Inc. makes no warranties, either express or implied, regarding the enclosed computer software package, its merchantability or its fitness for any particular purpose. The exclusion of implied warranties is not permitted by some states. The above exclusion may not apply to you. This warranty provides you with specific legal rights. There may be other rights that you have which may vary from state to state.

Apple software shall not be copied onto another diskette (except for archive purposes) or into memory unless as part of the execution of Termulator. When Termulator has completed execution, Apple software shall not be used by any other program.

©1986 THINK Technologies. Certain portions of this software are copyrighted by THINK Technologies, Inc.

PostScript is a trademark of Adobe Systems Incorporated. Apple, Macintosh, MultiFinder and LaserWriter are trademarks of Apple Computer, Incorporated. QMS is a registered trademark of Quality Micro Systems, Incorporated. Dataproducts is a registered trademark of Dataproducts Corporation. Linotronic is a trademark of Allied Corporation.

These documents are for informational purposes only and are subject to change without notice. New England Digital Corporation assumes no responsibility for any errors which may appear in these documents.

Document number D-SO-0790

This manual assumes that you are familiar with basic Synclavier and/or Direct-to-Disk operation. If you are unfamiliar with booting the system, using the trackball or moving around the terminal displays, please see the *Introduction* manual which includes basic operating instructions.

If the information you want is not in this manual, use the master index in the *Reference Guide*, to locate the proper manual.

## **Contents**

### *Setting up in the studio*

System maintenance	1.2
Signal flow charts	1.4
Synclavier technical data	1.6
Direct-to-Disk technical data	1.16

### *Track routing*

Synclavier track routing	2.2
Direct-to-Disk track and cuelist routing	2.8
Volume and gain	2.14
Selecting inputs	2.16

### *Digital transfer*

Introduction	3.2
Preparing for digital transfer	3.4
Digital transfer out	3.6
Digital transfer in	3.12
UDIO hardware specifications	3.16

### *Synchronizing to film and video*

Time code synchronization	4.2
Setting time code parameters	
Sequence Editor	4.8
Audio Event Editor	4.12
Keyboard Control Panel	4.18
Recording with SMPTE	4.20
Playing back with SMPTE	4.22
Generating SMPTE time code	4.24

*(continued next page)*

## ***Contents (con't)***

### *Synchronizing to audio tape (beat sync and 50 Hz)*

Synchronizing to an external source	5.2
Sync-to-tape	5.4
Two systems in sync	5.10

### *Special synchronization techniques*

Drum replacement	6.2
External click tracks	6.8
External repeat and arpeggiate	6.16

### *MIDI*

Introduction to MIDI	7.2
MIDI output parameters	7.10
MIDI input parameters	7.14
Single track recording and playback	7.20
Multitrack recording and playback	7.24
MIDI song pointer	7.34
Sending and receiving real-time effects	7.38
MIDI program changes	7.42
Displaying and editing MIDI messages	7.46
Synclavier MIDI implementation chart	7.51

<i>Index</i>	8.2
--------------	-----